To Make Foam

- 1. Prepare to make foam:
 - Start Generator, Air Compressor.
 - **Open** the Air Valve on the Compressor.
 - **Open** both Resin Tank and FAC Tank Main Valves on tanks (yellow at bottom).
 - **Open** the Large Three-Way Ball Valve toward Resin Pump (right).
 - **Push** reset button on FORD/Metering Box and enable pumps.
 - Tanks will start to circulate.
- 2. **Hook** RESIN and FAC Valves to the gun.
- 3. Attach Whip Hose to end of gun
- 4. Check setting of the Air Valve on the gun.
 - *Open the valve all the way*, obtaining maximum pressure
 - **Bend and crack the hose and** blow *all* remaining dried foam from hose
 - Once dried foam is removed, **reset** the Air Valve to starting position





- 5. *For this next step you will need:
 - A large 32-55 gal. garbage bag/can
 - Several Foaming Agent Catalyst boxes
 - A weigh scale

6. Check the foam:

- **Open** all three valves on the gun and pump foam into the large trash bag
- As you spray, *check the texture and weight* of the foam
- **Put an empty box** on the Scale and **zero out** the Scale
- When the foam has no residue, start to spray into the empty box
- 7. Continue spraying until the box is full.
 - Weigh the now full Foaming Agent Catalyst Box. The acceptable weight should read between 3.5 and 4.5 pounds while wet
 - Lower air pressure if weight is low; raise air pressure if weight is high
 - Keep filling and weighing foam in the empty boxes *until the proper weight is achieved*

This will ensure all the water is removed from the line