

To Make One Set of Foaming Agent/Catalyst (Soap)

1. Get set up:

- **Turn on** the Propane Tanks.
- **Hook up** water supply and **turn the water on.**
- **Turn on** the Propane for the Water Heater.
- **Start** the Generator. Turn on the Breaker for the Pumps.
- **Start Water Heater: *on button.***
- **Reset** Fill-Rite (Flow Meter) to 0.

2. **Open** Water Valve above FAC Tank. Fill tank with **47 gallons of hot water.**

3. **Shut down** fresh hot Water Valve once tank is filled.

4. **Slowly add 8 gallons** of foaming agent. ***Do not allow any foreign materials into tank!***

5. Mixture is now ready to make foam!